

943 SERIES



The new Prince Castle Tomato Saber[™] is the ideal tomato slicing system. Our exclusive Perma-Tight[™] blade cartridge never requires blade tightening or adjusting. The cartridge leaves our factory pretensioned for maximum performance. Blade replacement is fast and easy–simply snap the blade cartridge into place and the slicer is ready to use.

A contoured pusher head holds the tomato in place while slicing, and permanently lubricated Duralon[®] bearings assure the slicing stroke is smooth and quick. The exclusive Tomato Catcher snaps onto the unit and catches the sliced tomato for easy handling and less mess.

Constructed of aluminum, plastic and stainless steel, the Tomato Saber[™] is easy to clean – just spray it with water or run it through the dishwasher. Also, safety features such as the Blade Guard and Tomato Catcher keep the operator away from the slicing area, while the Table Stop and non-skid feet keep the unit stable.

943 SERIES TOMATO SABER™

STANDARD FEATURES

- New, exclusive, Perma-Tight[™] disposable blade cartridge system eliminates the need for blade tightening or adjusting.
- Contoured Tomato Pusher positions tomato as it passes through the blades.
- Includes Table Stop and exclusive Tomato Catcher.
- Built-in hand guard.
- Permanently lubricated bearings.
- Sturdy cast aluminum, plastic and stainless steel construction.
- Easy to maintain–no tools are required.
- Four models available: 3/16", 1/4", 3/8", 7/32" slices.
- Two-year warranty (excluding blade cartridge).

OPTIONS

Part No. Description 953 Core-It[®] 950-1 Core-It[®] Bulk Package of 144/Carton Model 953 Model 953 Cores tomatoes for no-waste slicing.

Stainless steel with easy-grip, plastic handle.

PRINCE CASTLE INC.

943 SERIES TOMATO SABER™

SPECIFICATIONS

DIMENSIONS

MODEL NUMBER	WIDTH IN. (CM)	HEIGHT IN. (CM)	LENGTH IN. (CM)	SHIPPING WT. LB. (KG.)	SHIPPING CU.FT. (CU.M.
943 Series	8.50 (21.60)	9.34 (23.72)	18.32 (46.50)	14(6.4)	.9 (.03)

ORDERING INFORMATION

MODEL DESCRIPTION 943-A ³/₁₆" (.48 cm) Slice Tomato Saber™ ¹/4" (.64 cm) Slice Tomato Saber™ 943-B 943-C ³/8" (.95 cm) Slice Tomato Saber™ 943-D ⁷/₃₂" (.55 cm) Slice Tomato Saber™ Perma-Tight[™] Replacement Blade Set (³/₁₆") for 943-A 943-038A 943-039A Perma-Tight[™] Replacement Blade Set (1/4") for 943-B 943-040A Perma-Tight[™] Replacement Blade Set (³/8") for 943-C 943-041A Perma-Tight[™] Replacement Blade Set (7/32") for 943-D

ACCESSORIES

MODEL	DESCRIPTION	
953	Tomato Core-It®	
	packaged one per card	
950-1	Tomato Core-It [®] bulk	
	package–144 per carton	
943-042	Slicer/Cutter Blade	
	Cleaning Brush	

